Signholders (Eclipse Convex)

1. Screw top and bottom graphic units together as shown (screw color may differ from instruction sheet) (fig. A).
2. Insert graphic into left upright channel (fig. B-1). Tuck graphic gently into right upright channel to complete installation (fig. B-2).

(A)

1" screws   1.25" screws

1" screws

(B)

(-1)

(-2)