

Portable Presentation Easel

1. Press down on hinges to open easel legs (fig. A).
2. Extend easel legs (fig. B) until push buttons lock into desired positions (fig. C).

Applicable Products:

425	426
425MG	427

