

Formulate Designer Series 10' Backwall - Kit 02

FMLT-DS-10-02

Formulate™ Designer Series 10ft displays have unique stylistic features and shapes, are portable and easy to assemble. The aluminum tube frame features snap-buttons and/ or spigot connections and zipper pillowcase fabric graphics. All displays come in portable, wheeled transit cases. Simply pull the pillowcase fabric graphic(s) over the frame and zip.



features and benefits:

- Premium aluminum tube frames with snap button/ spigot assembly
- Easy to store and ship
- Quick to set up
- Weighted feet for added stability
- Three zipper pillowcase fabric graphics
- One Lumina 200 LED Light
- Lifetime limited hardware warranty against manufacturer defects

dimensions:

Hardware	Graphic
<p>Assembled unit: 119.19" w x 105.41" h x 25.72" d 3027.5mm(w) x 2677.31mm(h) x 653.27mm(d)</p> <p>Approximate weight with cases: 66 lbs / 29.9 kgs</p>	<p>Please be sure to include a 2" bleed around the perimeter.</p> <p>Refer to related graphic template for more information.</p> <p>Visit: www.exhibitors-handbook.com/graphic-templates</p>
<p>Shipping</p> <p>Packing case(s): 1 OCE Case</p> <p>Shipping dimensions: 16.75" w x 64.25" h x 16.88" d 425.5mm(w) x 1632mm(h) x 428.8mm(d)</p> <p>Approximate total shipping weight (includes cases & graphics): 79 lbs / 35.8 kgs</p>	
<h3>additional information:</h3> <p>Graphic material: dye-sublimation zipper pillowcase fabric</p>	

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

Included In Your Kit


Tools, Components, & Connectors



ALLEN KEY SET x1




ES30 x14




LN114-SCRW x6



ES30-90B x6



STABILIZING BASE B-2 x2




STABILIZING BASE A x2




TC-30-A-90° x2


Graphics



FMLT-DS-10-02-A-G x1




FMLT-DS-10-02-B-G x1



FMLT-DS-10-02-C-G x1

Included In Your Kit


Tubes



DS-10-02-A-T1 x1



DS-10-02-A-T2 x4




DS-10-02-A-T3 x1




DS-10-02-A-T4 x2




DS-10-02-B-T1 x1



DS-10-02-B-T2 x2




DS-10-02-B-T3 x1



DS-10-02-B-T4 x8




DS-10-02-C-T1 x1





DS-10-02-C-T2 x1

PART CODE	QTY	DESCRIPTION
DS-10-02-A-T1	1	30MM STRAIGHT BOTTOM TUBE FOR FMLT-10-02
DS-10-02-A-T2	4	30MM STRAIGHT SIDE TUBE FOR FMLT-10-02
DS-10-02-A-T3	1	30MM STRAIGHT TOP TUBE FOR FMLT-10-02
DS-10-02-A-T4	2	30 MM CURVED CORNER TUBE FOR FMLT-10-02
DS-10-02-B-T1	1	30MM TOP CORNER FOR FMLT-10-02
DS-10-02-B-T2	2	30MM CURVED BOTTOM TUBE FOR FMLT-10-02
DS-10-02-B-T3	1	30MM CURVED TOP TUBE FOR FMLT-10-02
DS-10-02-B-T4	8	30MM STRAIGHT SIDE TUBE FOR FMLT-10-02
DS-10-02-C-T1	1	30MM CURVED TOP CORNER- RIGHT FOR FMLT-10-02
DS-10-02-C-T2	1	COPY OF DS-10-02-B-T3
ES-30	14	EXPANDING SPIGOT FOR 30MM TUBE
ES30-90B	6	30MM CORNER CONNECTOR WITH M10 INSERT
TC-30-A-90°	2	TC-30-A ASSEMBLED AT 90°
LN114-S2-450	2	LINEAR FOOT WITH COUNTERSUNK HOLES
LN114-S3	2	LINEAR FOOT FOR TWO FRAMES, 450MM X 100MM X 5MM
LN114-SCRW	6	M10X45MM SOCKET FLAT CAP SCREW, BLACK FINISH ALLOY STEEL
DS-10-02-A-G	1	FABRIC COVER FOR DS-10-02-A
DS-10-02-B-G	1	FABRIC COVER FOR DS-10-02-B
DS-10-02-C-G	1	FABRIC COVER FOR DS-10-02-C




Labeling Diagram

FMLT-DS-10-02



OVERHEAD VIEW





Kit Assembly

Step by Step


Step 1.

Locate the components necessary for assembling Frame A. Assemble your frame in order according to the "Labeling Diagram".




Step 2.

Locate the components necessary for assembling Frame B. Assemble your frame in order according to the "Labeling Diagram".




Step 3.

Locate the components necessary for assembling Frame C. Assemble your frame in order according to the "Labeling Diagram".



Step 4.

Fit graphic A onto Frame A. For ease of installation, pull the fabric cover over the top of the frame while the frame rests flat on the floor. Zip to enclose.




Kit Assembly

Step by Step


Step 5.

Fit graphic B onto Frame B. For ease of installation, pull the fabric cover over the top of the frame while the frame rests flat on the floor. Zip to enclose.




Step 6.

Fit graphic C onto Frame C. For ease of installation, pull the fabric cover over the top of the frame while the frame rests flat on the floor. Zip to enclose.



Step 7.

Locate both stabilizing Foot A assemblies. Attach the feet on the left of Frame B and the Right of Frame C. Tighten the lock screw on the side of the ES30-90B to lock your feet into place.



Step 8.

Locate both stabilizing Foot B-2 assemblies. Attach the feet on the left and right sides of frame A. Tighten in place using the lock screws. Connect frames A and C to the feet. Tighten the lock screw on the side of the ES30-90B to lock your feet into place.

