

Formulate Designer Series 10' Backwall - Kit 05

FMLT-DS-10-05

Formulate™ Designer Series 10ft displays have unique stylistic features and shapes, are portable and easy to assemble. The aluminum tube frame features snap-buttons and/ or spigot connections and zipper pillowcase fabric graphics. All displays come in portable, wheeled transit cases. Simply pull the pillowcase fabric graphic(s) over the frame and zip.



features and benefits:

- Premium aluminum tube frames with snap button/ spigot assembly
- Easy to store and ship
- Quick to set up
- Weighted feet for added stability
- Three zipper pillowcase fabric graphics
- Lifetime limited hardware warranty against manufacturer defects

dimensions:

Hardware	Graphic
<p>Assembled unit: 115.24" w x 98.27" h x 17.98" d 2927.06mm(w) x 2496mm(h) x 456.72mm(d)</p> <p>Approximate weight with cases: 66 lbs / 29.9 kgs</p>	<p>Please be sure to include a 2" bleed around the perimeter.</p> <p>Refer to related graphic template for more information.</p> <p>Visit: www.exhibitors-handbook.com/graphic-templates</p>
Shipping	
<p>Packing case(s): 1 OCE Case</p> <p>Shipping dimensions: 16.75" w x 64.25" h x 16.88" d 425.5mm(w) x 1632mm(h) x 428.8mm(d)</p> <p>Approximate total shipping weight (includes cases & graphics): 79 lbs / 35.8 kgs</p>	
additional information:	
<p>Graphic material: dye-sublimation zipper pillowcase fabric</p>	

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

Included In Your Kit


Tools, Components, & Connectors




ALLEN KEY SET x1




ES30 x26




LN114-SCRW x4



ES30-90B x2




STABILIZING BASE B-1 x2




LN114-S2-450 x2

Graphics



FMLT-DS-10-05-A-G x1




FMLT-DS-10-05-B-G x1



FMLT-DS-10-05-C-G x1

Included In Your Kit


Tubes




DS-10-05-A-T1 x2




DS-10-05-A-T2 x2



DS-10-05-A-T3 x4



DS-10-05-A-T4 x4




DS-10-05-A-T5 x1



DS-10-05-A-T6 x1



DS-10-05-A-T7 x1



DS-10-05-A-T5-M x1




DS-10-05-A-T6-M x1



DS-10-05-A-T7-M x1



DS-10-05-B-T1 x1




DS-10-05-B-T2 x1



DS-10-05-B-T3 x1




DS-10-05-B-T4 x1



DS-10-05-B-T5 x1

Included In Your Kit

Tubes




DS-10-05-B-T6 x1




DS-10-05-B-T7 x4

PART CODE	QTY	DESCRIPTION
DS-10-05_A-T1<As Machined>	2	30MM CURVED BOTTOM TUBE 1 FOR DS-10-05_B
DS-10-05_A-T2	2	30MM CURVED TOP TUBE 2 FOR DS-10-05_A
DS-10-05_A-T3	4	30MM CURVED SIDE TUBE 3 FOR DS-10-05_A
DS-10-05_A-T4	4	30MM STRAIGHT SIDE TUBE 4 FOR DS-10-05_A
DS-10-05_A-T5	1	30MM WELDED BOTTOM CORNER FOR DS-10-05_A
DS-10-05_A-T6	1	30MM WELDED TOP CORNER1 FOR DS-10-05_A
DS-10-05_A-T7	1	30MM WELDED TOP CORNER1 FOR DS-10-05_A
DS-10-05_A-T5-M	1	30MM WELDED BOTTOM CORNER FOR DS-10-05_A
DS-10-05_A-T6-M	1	30MM WELDED TOP CORNER1 FOR DS-10-05_A
DS-10-05_A-T7-M	1	30MM WELDED TOP CORNER1 FOR DS-10-05_A
DS-10-05_B-T1<As Machined>	1	30MM BOTTOM CORNER - LEFT FOR DS-10-05_B
DS-10-05_B-T2	1	30MM BOTTOM CORNER - RIGHT FOR DS-10-05_B
DS-10-05_B-T3	1	30MM TOP CORNER - LEFT FOR DS-10-05_B
DS-10-05_B-T4	1	30MM TOP CORNER - RIGHT FOR DS-10-05_B
DS-10-05_B-T5	1	30MM CURVED BOTTOM TUBE 5 FOR DS-10-05_B
DS-10-05_B-T6	1	30MM CURVED TOP TUBE 6 FOR DS-10-05_B
DS-10-05_B-T7	4	30MM STRAIGHT SIDE TUBE 7 FOR DS-10-05_B
ES-30	26	LINEAR FOOT FOR TWO FRAMES, 450MM X 100MM X 5MM
ES-30-90B	2	30MM CORNER CONNECTOR WITH M10 INSERT
M10 INSERT FOR 30MM TUBE	4	M10 INSERT FOR 30MM TUBE
LN114-SCRW	6	M10X45MM SOCKET FLAT CAP SCREW, BLACK FINISH ALLOY STEEL
LN114-S2-450	2	LINEAR FOOT WITH COUNTERSUNK HOLES
LN114-S3	2	LINEAR FOOT FOR TWO FRAMES, 450MM X 100MM X 5MM
DS-10-05_A-FABRIC COVER-M	1	FABRIC COVER-M FOR DS-10-05_B
DS-10-05_B-FABRIC COVER	1	FABRIC COVER FOR DS-10-05_B
DS-10-05_A-FABRIC COVER	1	FABRIC COVER FOR DS-10-05_A




Labeling Diagram

FMLT-DS-10-05



OVERHEAD VIEW




Kit Assembly

Step by Step



Step 1.

Gather the components necessary for assembling frame A and lay them flat on the floor. Assemble in the order the "Labeling Diagram" instructs. Lock your connectors into place using the provided allen key set.




Step 2.

Gather the components necessary for assembling frame B and lay them flat on the floor. Assemble in the order the "Labeling Diagram" instructs. Lock your connectors into place using the provided allen key set.




Step 3.

Gather the components necessary for assembling frame C and lay them flat on the floor. Assemble in the order the "Labeling Diagram" instructs. Lock your connectors into place using the provided allen key set.



Step 4.

With frame A laying flat on the floor, locate your pillowcase A graphic. With the pillowcase unzipped, encase frame A by covering the frame from top to bottom.




Kit Assembly

Step by Step


Step 5.

With frame B laying flat on the floor, locate your pillowcase B graphic. With the pillowcase unzipped, encase frame B by covering the frame from top to bottom.





Step 6.

With frame C laying flat on the floor, locate your pillowcase C graphic. With the pillowcase unzipped, encase frame C by covering the frame from top to bottom.



Step 7.

Gather both LN114-S2-450 assemblies, and 2 LN114 screws. Attach the foot to the curved side of Frame A and Frame C, in order as seen in the image to the right.



Step 8.

Gather both Stabilizing Foot B-1 assemblies, and 2 LN114 screws. Start by setting the hub on the foot into the ES30-90B. Next screw the foot and M10 spacer into frame B in the order shown on the right. Tighten the screw on the ES30-90B to lock in place.

